

WiFi Box

WiFi devices for window actuators control via smartphones and tablets

ShutterBox



WiFi device for the control of 230V window actuators via smartphone or tablet.

RwBox



WiFi device for the connection to wind and rain sensors and control of window actuators connected to the WiFi.

µRemotePro



Remote control with rechargeable batteries for the control of window actuators connected to the WiFi.

InBox



WiFi switches connection for the control of window actuators connected to the WiFi.

TempSensor



WiFi detector, equipped with waterproof measurement probe, for temperature indication and control of window actuators connected to the WiFi, based on detection and temperature changes.


AirSensor



WiFi detector for measuring the presence of polluting dust and display via smartphone or tablet with control of window actuators connected to the WiFi.

Compatible with IOS, Android, Alexa and Google assistant





WiFi devices for the control of window actuators via smartphones and tablets

8C0470 ShutterBox WiFi device for the control of 230V window actuators via smartphone or tablet.

8C0472 RwBox WiFi device for the connection to wind or rain sensors and control of window actuators connected to the WiFi.

8C0480 μ RemotePro remote control with rechargeable batteries for the control of window actuators connected to the WiFi.

8C0485 InBox WiFi switches connection for the control of window actuators connected to the WiFi.

8C0474 TempSensor WiFi detector, equipped with waterproof measurement probe, for temperature indication and control of window actuators connected to the WiFi, based on detection and temperature changes.

8C0475 AirSensor WiFi detector for measuring the presence of polluting dust and display via smartphone or tablet.

